















Partytent 4 m PVC Series






DANCOVER®

Part list.

Part No.	Part	6m	8m	10m
No. 01		8 PCS	10 PCS	12 PCS
No. 02		9 PCS	12 PCS	15 PCS
No. 04		8 PCS	10 PCS	12 PCS
No. 05		6 PCS	6 PCS	6 PCS
No. 06		6 PCS	9 PCS	12 PCS
No. 07		8 PCS	10 PCS	12 PCS
No. 08		27 PCS	31 PCS	35 PCS
No. 09		86 PCS	102PCS	118PCS
No. 10		18 PCS	18 PCS	18 PCS
No. 11		42 PCS	54 PCS	66 PCS
No. 12		4 PCS	4 PCS	4 PCS
No. 13		1 PCS	1 PCS	1 PCS
No. 14		6 PCS	8 PCS	10 PCS

Part list.


Part No.	Part	6m	8m	10m
No. 15		2 PCS	2 PCS	2 PCS
No. 16		8 PCS	10 PCS	12 PCS
No. 17		4 PCS	4 PCS	4 PCS

WWW.Dancovershop.com

Assembly

Step 1: Lay out all roof tubes and connectors as shown.


Step 2: Join the roof tubes and connectors from middle and out. See *Roof Assembly*.



Step 3: Apply legs in one side as shown.


Step 4: Put the roof cover on and tie down with bungeeballs as shown.

* Note: Tie some of the bungees in one side and then some in the other. Continue this until all bungees are in place



Step 5: Raise the legs in the opposite site.



Step 6: Make sure the cover is fastened.





Step 7: Attach sidewalls with bungeeballs as shown.

Step 8: Attach endwalls with bungeeballs As shown.

Step 9: Connect the legs and the leg covers using the hooks as shown.



Roof Assembly



- Step 1:** Lay out all roof tubes and connectors as shown above.
- Step 2:** Join the roof tubes and connectors from middle and out.

DANCOVER®

Contact Information

Head office:

Dancover A/S
Nordre Strandvej 119 G
3150 Hellebæk
Danmark

National Contact:

Denmark:
mail@dancover.dk
70267620

Spain:
Espana@dancover.com
911 436 828

UK:
Mail@dancover.co.uk
020 8099 7570

Italy:
italia@dancover.com
02 479 21 198

Germany:
mail@dancover.de
0 41 02 66 7040

Switzerland:
schweitz@dancover.com
0 840 000 125

France:
france@dancover.com
0975 180 589

Austria:
austria@dancover.com
0662 626 935

Sweden:
mail@dancover.se
0 40 233 262

Norway:
norge@dancover.dk
23 10 06 90